

HOW TO ADJUST YOUR RH NEW LOGIC


DESIGNED FOR HUMAN
PERFORMANCE

1



HEIGHT OF THE CHAIR

2



SEAT DEPTH

3



BACKREST ANGLE

4



BACKREST HEIGHT

5



UNLOCK THE DYNAMIC
TILT

6



TILT RESISTANCE

7



LUMBAR PUMP

8



ADJUSTABLE ARMREST
Height, width, depth, turnable

9



ADJUSTABLE NECKREST
Height & depth

